


Navigation Chart IND

To enter configuration:
Keep the  button pressed and then apply power

To save changes:
Come to  and then press  to save the changes



APMAN®