
## tapman<sup>®</sup>

## SINGLE OUTPUT **PID CONTROLLER**

**OPERATING INSTRUCTIONS** Model: PID1



## Congratulations on selecting this state of the art microcontroller based instrument.

Please read the following before use

WARNING Serious injury may result if instructions are not followed.

This unit is not designed as a safety device.

- \* Failure of devices, such as the thermocouple/ RTD sensor, heater, output Relay, SSR or temperature controller itself can result in severe damage to a product while in process, melting of the heater or a damaging fire.
- \* An over-temperature protection device must be installed in your process that will remove all power from the heating circuit if the above failure occurs.
- \* Failure to install temperature limiting control protection where a potential hazard exists could result in damage to equipment and property and fatal injury to personal.

**CAUTION** Product may be damaged of any result if instructions are not followed. Product may be damaged or injury may

- > This unit should be installed in a panel. >Do not use the instrument outdoors.
- > The protection device of this unit may be damaged if instructions are not followed.
- >Do not use the instrument in places where there is excessive of dust, corrosive gases, oil spilling, high humidity, condensation, direct sunshine, radiant heat, vibration, shock occur.
- >Unused terminals should not be used as jumper. As they may be connected internally.
- >Clean the unit with dry cloth only after turning the power off. >Do not modify or disassemble the unit.
- >Power switch or a circuit breaker should be installed near the
- unit in order to cut the power supply. > Do not connect power to sensor terminals.

# Set Value Adjustment

The Set value can be adjusted when the controller is displaying the process temperature.

- Press the 
  button. The display shows the SET VALUE.
- To change; keep the 
  button pressed and using either (a) or (c) button to increase or decrease the set value respectively.
- <sup>CP</sup>Keeping either (a) or (b) button pressed for more than 2 seconds will result in a rapid change of the value.

# Configuration

Before the controller can be used, it has to be configured properly. This can be done as follows:


- $\checkmark$  Remove power to the controller.
- ✓ Keep the button pressed and then apply power.
- $\checkmark$  When the display shows  $\Box_{nF}$  release
- $\checkmark$  On releasing the  $\odot$  button the display shows ESE. \*\*\*
- $\checkmark$  Press the a button briefly the display shows 55. Now press the 
  button. The display now shows the selected sensor.
- ✓ Press ⓐ or ⑨ button to change the sensor.
- $\checkmark$  After the desired sensor is displayed, press the 


  button again. The display now shows **SEn** again.
- ✓ Using (a) or (a) buttons navigate through the other configuration parameters.
- ✓ To change the value of any and then using (a) or (c) change to the desired value.
- $\checkmark$  After all the changes have been done use or button to comeback to ESE.

✓ To save the changes made, press the • button when the display is still showing ESE.

# **Config Parameters** † is the factory default value.

5En **Sensor Selection** 





#### h95 **Hysteresis Value**

Hysteresis value in °C effective only when the controller is running in HEAT or COOL Mode.

Range: 0.2 - 99.9 °C + : 2.0 °C



This is the PID Gain.


Range: 1.0 - 99.9 3 Digit model 1.0 - 199.9 4 Digit Model **†** : 6.0

#### in-E **Integral Time**

This is the Integral time.

Range: 10 - 999 3 Digit model 10 - 5000 4 Digit Model

**†**:250



Operator will not be able to set the set point more than this value. Can be used to set the upper limit of Set point.



Pressing the 
button at this parameter will save the changes and make the controller come out of config mode.

### **ERROR** Diagnosis

The instrument display flashes Condition 1: Sensor selected is Thermocouple:

Cause: Sensor is open or internal cold junction compensation circuit is damaged.

- Short Terminals 1 and 2 together and then check again. →If the display still flashes then the problem is internal to the unit. In this case send back the unit to the factory for service.
- → If the display starts showing the room temperature, then check the wiring connection to the thermocouple.

#### Condition 2: Sensor selected is RTD: Cause: Sensor is open or short circuited.

- →Connect a known good sensor to the unit and then check again
- →If the display no longer flashes then check the wiring connection to the RTD

## **Sensor Ranges**

Sensor	3 Digit Model		4 Digit Model	
	Min	Max	Min	Max
Pt100 <sub>DIN</sub>	-99°C	660°C	-160°C	660°C
J	-99°C	870°C	-200°C	870°C
K	-99°C	999°C	-190°C	1300°C
Pt100 <sub>DIN</sub>	N.A	N.A	-160.0°C	660.0°C

